



FITTING INSTRUCTIONS

12 Churchill way, Fleckney, Leicester, LE8 8UD

0116 2402 968

<https://amber-valley.com/>

Fitting Instructions For Heavy Duty Plant Alarms

Always fit horizontally facing the rear

- 1.Red Lead to Reverse Lamp
- 2.Black Lead to Earth
- 3.Green Lead to Horn Lamp (Continuous mode)

If GREEN Lead not required connect to BLACK Lead