



FITTING INSTRUCTIONS

12 Churchill way, Fleckney, Leicester, LE8 8UD

0116 2402 968

<https://amber-valley.com/>

Indicator Alarmlight Fitting Instructions

- 1.Red Lead to Constant Power
- 2.Black Lead to Earth
- 3.Green Lead to Operating Indicator
- 4.White Lead to other side of flasher unit to mute
- 5.Orange to switch on dashboard for half volume

Fitting Instructions For Part Numbers: AVAL2-14CLHO, AVAL2-14CRHO, AVAL3-14CLHO, AVAL3-14CRHO