



# FITTING INSTRUCTIONS

12 Churchill way, Fleckney, Leicester, LE8 8UD

0116 2402 968

<https://amber-valley.com/>

## Speed Module Fitting Instructions

MPH	SWITCH ON	MPH	SWITCH ON
4	3	30	2,3,4,5
6	2, 3	35	1,2,6
8	4	40	4,6
10	2, 4	45	1,3,4,6
12	3, 4	50	2,5,6
15	1,2,3,4	56	4,5,6
20	3, 5	60	2,3,4,5,6
25	1,4,5	63	1,2,3,4,5,6



NOTE: All road speeds assume 4 pulse per metre.